







MADE IN GERMANY




THE PAN MANUFACTORY

Pans 
Pots 
Roasters 
Woks 
Special 
Accessories 

gastro
holding
CANDOLA
VÁŠEŇ PRO STOLOVÁNÍ
www.candola.cz


Eurolux®



Frying Pan	Ø cm	Height cm	Item No.	Item No.
Frying Pan	20	≈ 5,0	EU120	EU120-3
Frying Pan	24	≈ 5,0	EU124	EU124-3
Frying Pan	26	≈ 5,0	EU126	EU126-3
Frying Pan	28	≈ 5,0	EU128	EU128-3
Frying Pan	32	≈ 5,0	EU132	EU132-3



Braising pan	Ø cm	Height cm	Item No.	Item No.
Braising pan	20	≈ 7,0	EU220	EU220-3
Braising pan	24	≈ 7,0	EU224	EU224-3
Braising pan	26	≈ 7,0	EU226	EU226-3
Braising pan	28	≈ 7,0	EU228	EU228-3



Square braising pan	Ø cm	Height cm	Item No.	Item No.
Square braising pan	24 x 24	≈ 6,5	EU324-S	EU324-S-3
Square braising pan	28 x 28	≈ 6,5	EU328-S	EU328-S-3



Grill pan	Ø cm	Height cm	Item No.	Item No.
Grill pan	28 x 28	≈ 4,5	EU327-1	EU327-1-3



Fish pan	Ø cm	Height cm	Item No.	Item No.
Fish pan, with removable handle	38 x 28	≈ 5,0	-	EU138-3-AB



Crêpes pan / Pancake pan	Ø cm	Height cm	Item No.	Item No.
Crêpes pan	28	-	-	EU328-C-3



Egg pan	Ø cm	Height cm	Item No.	Item No.
Egg pan, with 4 cavities	26	≈ 4,0	-	EU126-E-3

The item numbers apply to ceramic, gas and electro stoves.

Items for induction (suitable for all types of stoves) are expanded by the addition -3.

All Eurolux items with fixed handle are also available with removable handle or stainless steel handle.

The item number is in this case expanded by the addition -AB or -ES.

Add the surcharge listed below for the removable handle or stainless steel handle to the respective unit price.

Handles	Item No.
Removable handle	-AB
Stainless steel handle	-ES



Saucepot with spouts	Ø cm	Height cm	Item No.	Item No.
Saucepot, ≈ 1.5 L	18	≈ 10,0	EU150	EU150-3



Cooking pot	Ø cm	Height cm	Item No.	Item No.
Cooking pot, ≈ 3.0 L	20	≈ 12,5	EU300	EU300-3
Cooking pot, ≈ 3.0 L + glass lid	20	≈ 12,5	EU300-SET	EU300-SET-3
Cooking pot, ≈ 4.5 L	24	≈ 12,5	EU450	EU450-3
Cooking pot, ≈ 4.5 L + glass lid	24	≈ 12,5	EU450-SET	EU450-SET-3
Cooking pot, ≈ 6.6 L	28	≈ 12,5	EU650	EU650-3
Cooking pot, ≈ 6.6 L + glass lid	28	≈ 12,5	EU650-SET	EU650-SET-3
Cooking pot, ≈ 8.5 L	28	≈ 17,0	EU860	EU860-3
Cooking pot, ≈ 8.5 L + glass lid	28	≈ 17,0	EU860-SET	EU860-SET-3



Casserole	Ø cm	Height cm	Item No.	Item No.
Casserole, ≈ 2.0 L	20	≈ 7,0	EU520	EU520-3
Casserole, ≈ 3.0 L	24	≈ 7,0	EU524	EU524-3
Casserole, ≈ 3.5 L	26	≈ 7,0	EU526	EU526-3
Casserole, ≈ 4.0 L	28	≈ 7,0	EU528	EU528-3
Casserole, ≈ 5.5 L	32	≈ 7,0	EU532	EU532-3



Deep casserole	Ø cm	Height cm	Item No.	Item No.
Deep casserole, ≈ 3.0 L	20	≈ 10,0	EU720	EU720-3
Deep casserole, ≈ 3.0 L + glass lid	20	≈ 10,0	EU720-SET	EU720-SET-3
Deep casserole, ≈ 4.5 L	24	≈ 10,0	EU724	EU724-3
Deep casserole, ≈ 4.5 L + glass lid	24	≈ 10,0	EU724-SET	EU724-SET-3
Deep casserole, ≈ 5.0 L	26	≈ 10,0	EU726	EU726-3
Deep casserole, ≈ 5.0 L + glass lid	26	≈ 10,0	EU726-SET	EU726-SET-3
Deep casserole, ≈ 6.0 L	28	≈ 10,0	EU728	EU728-3
Deep casserole, ≈ 6.0 L + glass lid	28	≈ 10,0	EU728-SET	EU728-SET-3
Deep casserole, ≈ 8.5 L	32	≈ 10,0	EU732	EU732-3
Deep casserole, ≈ 8.5 L + glass lid	32	≈ 10,0	EU732-SET	EU732-SET-3



Square Casserole	Ø cm	Height cm	Item No.	Item No.
Square casserole, ≈ 3.0 L	24 x 24	≈ 7,0	EU325	EU325-3
Square casserole, ≈ 3.5 L	26 x 26	≈ 7,0	EU326	EU326-3
Square casserole, ≈ 4.0 L	28 x 28	≈ 7,0	EU328	EU328-3



Square deep casserole	Ø cm	Height cm	Item No.	Item No.
Square d. casserole, ≈ 4.5 L	24 x 24	≈ 10,0	EU323	EU323-3
Square d. casserole, ≈ 4.5 L + glass lid	24 x 24	≈ 10,0	EU323-SET	EU323-SET-3
Square d. casserole, ≈ 6.0 L	28 x 28	≈ 10,0	EU330	EU330-3
Square d. casserole, ≈ 6.0 L + glass lid	28 x 28	≈ 10,0	EU330-SET	EU330-SET-3

Eurolux[®]



Wok	Ø cm	Height cm	Item No.	Item No.
Wok Ø 32 cm	32	≈ 10,0	EU832	EU832-3
Wok Ø 36 cm	36	≈ 10,0	EU836	EU836-3



Roasting dish	Ø cm	Height cm	Item No.	Item No.
Roasting dish, ≈ 3.5 L	32 x 25	≈ 7,0	-	EU1005-3
Roasting dish, ≈ 3.5 L + glass lid	32 x 25	≈ 7,0	-	EU1005-SET-3



Roasting dish	Ø cm	Height cm	Item No.	Item No.
Roasting dish*, ≈ 6.5 L	41 x 26	≈ 8,0	-	EU1006-3

* with anti-slip silicone inserts



Roasting dish, deep	Ø cm	Height cm	Item No.	Item No.
Roasting dish, ≈ 7.0 L	33 x 22	≈ 11,0	EU800	EU800-3
Roasting dish, ≈ 7.0 L + glass lid	33 x 22	≈ 11,0	EU800-SET	EU800-SET-3



Roasting dish	Ø cm	Height cm	Item No.	Item No.
Roasting dish, ≈ 8.5 L	40 x 27	≈ 13	-	EU1000U-3
Lid, ≈ 3.3 L	40 x 27	≈ 6,5	-	EU10010-3
Roasting dish set XL (roaster + lid)	40 x 27		-	EU1000-SET-3
Roasting dish set* (roaster + lid)	33,5 x 23,5		-	EU1035-SET-3

* with anti-slip silicone inserts

The item numbers apply to ceramic, gas and electric stoves.



Items for induction (suitable for all types of stoves) are expanded by the addition -3.



www.candola.cz





Grill plate	Ø cm	Height cm	Item No.	Item No.
Grill plate, fully ribbed	36,5 x 21,5	2,5	-	EU1002-3



Grill plate	Ø cm	Height cm	Item No.	Item No.
Grill plate, smooth	43 x 28	2,5	-	EU2000-3
Grill plate, half ribbed	43 x 28	2,5	-	EU2001-3
Grill plate, fully ribbed	43 x 28	2,5	-	EU2002-3



Grill plate with handles	Ø cm	Height cm	Item No.	Item No.
Grill plate, with handles	41 x 24	2,5	-	EU1003-3
Grill plate, w. stainless steel handles	41 x 24	2,5	-	EU1003-3-ES



Teppanyaki plate with handles	Ø cm	Height cm	Item No.	Item No.
Teppanyaki plate, with handles	41 x 24	2,5	-	EU1004-3
Teppanyaki plate, w. stainless steel handles	41 x 24	2,5	-	EU1004-3-ES



IMPORTANT NOTE

On the induction versions of our grill plates, Teppanyaki plate we have a patented system of embedded silicone inserts to avoid that the products slipping on your hob / stove, which ensures easier handling. The silicone inserts are only suitable for use on induction hobs / stoves, please remove these before use on electric, ceramic or gas hobs / stoves / spoils.


The item numbers apply to ceramic, gas and electro stoves.





Items for induction (suitable for all types of stoves) are expanded by the addition -3.






Frying Pan		Ø cm	Height cm	Item No.	Item No.
Frying Pan		20	≈ 4,5	EUS120	EUS120-3
Frying Pan		24	≈ 4,5	EUS124	EUS124-3
Frying Pan		28	≈ 4,5	EUS128	EUS128-3
Frying Pan		32	≈ 4,5	EUS132	EUS132-3


Braising pan		Ø cm	Height cm	Item No.	Item No.
Braising pan		24	≈ 6,5	EUS224	EUS224-3
Braising pan		28	≈ 6,5	EUS228	EUS228-3

Squrre braising pan		Ø cm	Height cm	Item No.	Item No.
Square braising pan		20 x 20	≈ 6,5	EUS320	EUS320-3
Square braising pan		24 x 24	≈ 6,5	EUS324	EUS324-3
Square braising pan		28 x 28	≈ 6,5	EUS328	EUS328-3

Milk pot		Ø cm	Height cm	Item No.	Item No.
Milk pot, 1.5 L		16	≈ 9,5	EUS150	EUS150-3
Milk pot, 2.0 L		18	≈ 10	EUS200	EUS200-3

Wok		Ø cm	Height cm	Item No.	Item No.
Wok Ø 30 cm		30	≈ 10	EUS830	EUS830-3



The item numbers apply to ceramic, gas and electro stoves. 

Items for induction (suitable for all types of stoves) are expanded by the addition -3. 


All Eurolux items with fixed handle are also available with removable handle or stainless steel handle.

The item number is in this case expanded by the addition -AB or -ES.

Add the surcharge listed below for the removable handle or stainless steel handle to the respective unit price.

Handles		Item No.
Removable handle		-AB
Stainless steel handle		-ES

Pyrex® Glass lids incl. lid knob

		Item No.
16 cm Ø		016-DK-EU
18 cm Ø		018-DK-EU
20 cm Ø		020-DK-EU
24 cm Ø		024-DK-EU
26 cm Ø		026-DK-EU
28 cm Ø		028-DK-EU
32 cm Ø		032-DK-EU

Tempered glass lids incl. lid knob

		Item No.
30 cm Ø		S30-DK-EU
36 cm Ø		S36-DK-EU

Pyrex® Square glass lids incl. lid knob

		Item No.
26 x 26 cm		0026-DK-EU
28 x 28 cm		0028-DK-EU

Square tempered glass lids incl. lid knob

		Item No.
20 x 20 cm		S220-DK-EU
24 x 24 cm		S224-DK-EU
32 x 25 cm (für Bratreine)		S1005-DK-EU

Borosilicate Glas Lid

		Item No.
33 x 22 cm (for roasting dish EU800)		0800-00

Accessories

	Item No.
Fixed handle	EU-S
Removable handle	EU-S-AB
Side handle (one piece)	EU-G
Lid knob	EU-DK



Item No. EU-S



Item No. EU-S-AB



Item No. EU-G




Item No. EU-DK

Glass lid, lid knobs, fixed handle and handles heat-resistant up to 240 °C / removable handle heat-resistant up to 160 °C

Bag

		Item No.
Eurolux bag (non woven)		EU-BAG

Pan protector Set, 3 pieces

		Item No.
3 pcs. pan protector, dark grey		KH020



GERMAN
DESIGN
AWARD
WINNER
2020

ethical
ambiente style

www.candola.cz